



# SIME HIDRA



Item	Part Number	Description	Qty.
1	075-0001-0	Body (301094)	1
2	075-0002-0	Arm (301095)	1
3	075-0003-0	Housing outer (3010092)	1
4	075-0004-0	Housing inner (301097)	1
7	075-0005-0	Cap (30972)	1
8	075-0006-0	Spring (30971)	1
10	075-0007-0	Spring (301098)	1
10a	075-0008-0	Spring cap (301099)	1
11	075-0009-0	Bushing, 44 x 34.2 x 2 (301088)	1
11a	075-0010-0	Washer, 47 x 34.2 x 2 (301089)	1
12a	075-0011-0	Spring (301090)	1
13	075-0012-0	Washer, Bearing (301088)	2
14		Nozzle, (3010100)	1
15	075-0014-0	Arm (30358)	1
16	075-0015-0	Screw (30359)	1
18	075-0016-0	Shift Brkt. (3010101)	1
19	075-0017-0	Shift Trip Brkt. (3010102)	1
19a	075-0017-1	Pin (30363)	1
20	075-0018-0	Trip Brkt. (3010103)	1
20a	075-0019-0	Pin (3010107)	1
21	075-0020-0	Trip over center part (30816)	1
22	075-0021-0	Spring (30817)	1

# SIME HIDRA



Item	Part Number	Description	Qty.
24	075-0022-0	Cover (30819)	1
25	075-0023-0	Screw (30820) (Includes 25a & 38)	2
26	075-0025-0	Cap (3010194)	1
27		Bolt, M5 x 22	1
27a		Nut, M5	1
28	075-00260	Nozzle (30280)	1
29	075-0027-0	Bracket (30339)	1
30		Cotter pin	1
34	075-0039-0	Tube (3010106)	1
35		Bolt (30336)	1
37	075-0040-0	Spring (30337)	1
37	075-0041-0	Spring (30374)	1