

Bellows Problem Scenario


Problem:

Bellows will not fill and water is running from the discharge hose



Bellows Problem Solutions

- Carefully remove the tube from the Elbow beside the high low valve. If pressurized water is coming from this line, valve block is faulty and should be repaired or replaced.



Bellows Problem Solutions

- If your unit is equipped with a Quick Exhaust Valve, check to see if water is running through it. If water is running through the Quick Exhaust Valve and not filling the Bellows the Quick Exhaust Valve needs to be replaced.

