




KOMET TWIN 101 PLUS

KOMET TWIN 140 PLUS



No.	101 Part Number	140 Part Number	Description	Qty.
B.00.0	077-0135-0	077-0135-0	Assembly- Housing/Flange	1
B.00.1	077-0136-0	077-0136-0	Assembly- Housing / 2"	1
B.1	077-0137-0	077-0137-0	Housing Cover	1
B.2	077-0138-0	077-0138-0	Housing	1
B.3	077-0139-0	077-0139-0	Base	1
B.4	077-0140-0	077-0140-0	Adapter/ Flange	1
B.5	077-0141-0	077-0141-0	Adapter/ thread 2" BSPF	1
B.6	077-0142-0	077-0142-0	Adapter/ thread 2" NPTF	1
B.7	077-0143-0	077-0143-0	Trip Stop Ring	2
B.00-2	077-0144-0	077-0144-0	Assembly - Main Bearing	1
B.8	-----	-----	Bearing Disk	1
B.9	-----	-----	O-Ring	1
B.00-3	077-0145-0	077-0145-0	Assembly- Brake	1
B.10	-----	-----	Glide Ring	1
B.11	-----	-----	Main Seal	1
B.12	-----	-----	Brake Pad	8
B.13	077-0146-0	077-0146-0	O-Ring	1
B.14	077-0147-0	077-0147-0	Brake Spring	4
B.15	077-0148-0	077-0148-0	Bolt	6
B.16	077-0149-0	077-0149-0	Nut	6
B.17	077-0150-0	077-0150-0	O-ring	1
B.18	077-0151-0	077-0151-0	Bolt	4



KOMET TWIN 101 PLUS

KOMET TWIN 140 PLUS

No.	101 Part Number	140 Part Number	Description	Qty.
D.00-0	077-0152-0	077-0223-0	Assembly- Barrel Standard Type- (Contains Items Noted with ^)	1
D.00-1	077-0153-0		Assembly- Barrel Waste Water Type-4 Vains (Contains Items Noted with ^)	1
D.00-2	077-0154-0	077-0225-0	Assembly- Barrel- Bracket Standard Type	1
D.00-3	077-0155-0		Assembly- Barrel- Bracket Waste Water Type - 4 Vains	1
^ D.1	-----	-----	Flange	1
^ D.2	-----	-----	Tube	1
^ D.3	077-0156-0	077-0156-0	Rod Bushing	1
^ D.4	077-0157-0	077-0157-0	Gauge Plug	1
D.5	077-0158-0	077-0158-0	Bolt	2
D.6-P	077-0159-0	077-0159-0	O-Ring	1
D.7	077-0160-0	077-0160-0	Nut	2
D.8	077-0161-0	077-0161-0	Nozzle Cap BC/U	1
D.9	077-0162-0	077-0162-0	Taper Bore Nozzle UN	1
D.11	077-0163-0	077-0163-0	Service Key CH/BCU	1
^ D.12	-----	-----	Bolt	2
^ D.13	-----	-----	Nut	2
^ D.14	-----	-----	Washer	2
^ D.15	077-0164-0	077-0164-0	Gasket	1
F.00-0-P	077-0165-0	077-0165-0	Assembly - Trip Leverage - (Contains Items Noted with	1
F.00-1-P	077-0166-0	077-0166-0	Assembly - Bracket - (Contains Items Noted with ^)	1
^ F.1-P	-----	-----	Bracket	1
^ F.2	077-0167-0	077-0167-0	Stop Pad	2
^ F.3	077-0168-0	077-0168-0	Circlip	2
F.4	077-0169-0	077-0169-0	Dust Ring	1
F.5	077-0170-0	077-0170-0	Bolt	2
F.6	077-0171-0	077-0171-0	Nut	2
F.00-2-P	077-0172-0	077-0172-0	Assembly - Shift Lever Front (Contains Items Noted with *)	1
* F.7	-----	-----	Shift Lever Front	1
* F.8	-----	-----	Bushing	4
* F.9	-----	-----	Seal	2
* F.10	-----	-----	Seal	1
* F.11-P	-----	-----	Fulcrum Shaft for Drive Arm	1
* F.12	-----	-----	Cap	2
* F.13	-----	-----	Plug	1
* F.14	077-0173-0	077-0173-0	Washer	4
* F.15-P	077-0174-0	077-0174-0	Cover	1
* F.16	077-0175-0	077-0175-0	Washer	1
* F.17	077-0176-0	077-0176-0	Spring housing Int	1
* F.18-P	077-0177-0	077-0177-1	Spring Drive Arm	1
* F.19-P	077-0178-0	077-0178-0	Spring Housing Ext.	1
* F.20	077-0179-0	077-0179-0	Washer	1
* F.21	077-0180-0	077-0180-0	Washer	1
* F.22	077-0181-0	077-0181-0	Bolt	1
F.00-3-P	077-0182-0	077-0182-0	Assembly- Shift Lever Rear (Contains Items Noted with #)	1
# F.23-P	-----	-----	Shift Lever Rear	1
# F.24	-----	-----	Bushing	2
# F.25	-----	-----	Seal	1
# F.26	-----	-----	Washer	1
# F.27-1	077-0183-0	077-0183-0	Pin	1
F.00-4	077-0184-0	077-0184-0	Assembly - Trip Spring (Contains Items Noted with ~)	1
~ F.28	-----	-----	Bolt	2
~ F.29	-----	-----	Washer	2
~ F.30	-----	-----	Spring Guide	1
~ F.31	-----	-----	Trip Spring	1
~ F.32	-----	-----	Guide	1
~ F.33	-----	-----	Stopper	1



KOMET TWIN 101 PLUS

KOMET TWIN 140 PLUS

	No.	101 Part Number	140 Part Number	Description	Qty.
	F.00-5	077-0185-0	077-0185-0	Assembly- Trip Bolt (Contains Items Noted with @)	1
@	F.34	-----	-----	Bolt	1
@	F.35	-----	-----	Spring	1
@	F.36	-----	-----	Washer	1
	F.37	077-0186-0	077-0257-0	Reverse Rod	1
	F.00-6-P	077-0187-0	-----	Assembly- Stopper (Contains Items Noted with \$)	1
\$	F38-P	-----	-----	Bolt	2
\$	F.39-P	-----	-----	Stopper for drive arm	1
\$	F.40-P	-----	-----	Nut	2
	F.41	077-0188-0	077-0259-0	Reverse Rod for Vari-Angle	1
	G.1	077-0189-0	077-0189-0	Elbow 24°	1
	G.2	077-0190-0	077-0190-0	Elbow 21°	1
	G.3	077-0191-0	077-0191-0	Elbow 18°	1
	G.4	077-0192-0	077-0192-0	Bolt	3
	G.5	077-0193-0	077-0193-0	Washer	3
	G.6	077-0188-2	077-0259-2	O-Ring	1
	G.7	077-0188-1	077-0259-1	Gasket	1
	H.00-0-P	077-0196-0	077-0196-0	Assembly- Drive Arm - Standard	1
	H.00-W-P	077-0197-0	-----	Assembly- Drive Arm Waste Water	
	H.1-P	-----	-----	Drive Arm	1
	H.00-1-P	077-0198-0	077-0198-0	Assembly - Deflector- Standard (Contains Items Noted with ^)	1
	H.00-2-P	077-0199-0	-----	Assembly- Deflector - Waste Water (Contains Items Noted with ^)	
^	H.2-P	-----	-----	Deflector	1
	H.3-P	077-0200-0	077-0200-0	Bolt	2
^	H.4-P	-----	-----	Screw	3
	H.5-P	077-0201-0	077-0201-0	Bolt	1
	H.6-P	077-0202-0	077-0202-0	Nut	1
^	H.7-P	-----	-----	Washer	3
^	H.8-P	-----	-----	Washer	3
	UPG	077-0203-0	077-0203-0	Upgrade SR	1
	M.00-0-P	077-0204-0	077-0204-0	Assembly- Jet Brake (Contains Items Noted with *)	1
*	M.1-P	-----	-----	Support	1
*	M.2-P	077-0205-0	077-0205-0	Blade	1
*	M.3-P	-----	-----	Bolt	1
*	M.4-P	-----	-----	Washer	1
*	M.5-P	-----	-----	Bolt	1
*	M.6-P	-----	-----	Washer	2
*	M.7-P	-----	-----	Nut	2